# Cleaning CD

## Cleaning

**Clean all your CD players.**

Cleaning CD for CD players

### Specifications:

• With recorded instructions.
• A dry high-performance CD player cleaning system.
• Maximum uses : 30.

*Regular cleaning after each 10 to 15 playing hours is recommended in order to keep your unit in best working order.*

**Packing dimensions (LxHxD):**
15,6x25,5x1,4 cm

| Ref | Barcode | Packing | Inner pack |
|---|---|---|---|
| NCD105 | 3303170013410 | 100 | 10 |